



**Bienvenido**

Todo lo que desee saber para el correcto funcionamiento de su refrigerador se encuentra aquí. Lo invitamos a conocerlo y sacar el máximo provecho de él.

**Guía rápida**

- 1** Seleccione un área amplia, limpia y sin humedad.
- 2** Quite todo el material de empaque cintas, cartones, bolsas de plástico y demás.
- 3** Colocación: Para que circule el aire, deje espacios de 5 cm a ambos lados; detrás, 10 cm, y arriba, de 5 a 10 cm.
- 4** Deje reposar el refrigerador de 6 a 8 horas para que se asiente el gas.
- 5** Antes de conectarlo, limpie el equipo con un trapo o esponja suave y jabón neutro.
- 6** Conéctelo. Antes de llenarlo, deje que funcione vacío y cerrado durante 4 horas.

- No use extensiones.
- No conecte otros aparatos en el mismo contacto.
- Sujete el conector por la clavija, no por el cable.
- Su refrigerador está provisto de un tomacorriente polarizado tipo «Y» con cable a tierra integrado. No elimine la terminal de tierra ni use adaptadores.
- Si el cordón de alimentación es dañado, este debe sustituirse por el fabricante, por su agente de servicio autorizado o por personal calificado con el fin de evitar un peligro.
- Si en su región suele haber variaciones de voltaje, use un regulador de voltaje con capacidad de 500 a 1000 Watts.


**Importante:** Si no sigue las advertencias y pasos anteriores, usted es enteramente responsable de los daños personales o materiales que pueda sufrir con el uso de este equipo.

**Instrucciones generales**

Es muy importante:  
a) leer las instrucciones técnicas antes de instalar este artefacto;  
b) leer las instrucciones de uso antes de encender este artefacto.

Este aparato no está previsto que sea utilizado por personas (incluidos niños) con capacidades físicas, sensoriales o mentales reducidas, o con falta de experiencia y conocimiento, excepto que se le haya dado instrucción o supervisión referida al uso del aparato por una persona responsable de su seguridad. Los niños se deben supervisar para asegurar que no jueguen con el aparato.

**COLOCACIÓN**  
Para que su refrigerador funcione bien, debe circular aire alrededor. Revise el punto 3 de la Guía Rápida.  
No coloque el refrigerador cerca de fuentes de calor (estufas, hornos, calentadores) ni lo exponga al sol.  
**Nota:** Las puertas de estos modelos no son reversibles.




modelo y capacidad (L)	dimensión total (puertas cerradas)		espacio total requerido (puertas abiertas)	
	profundidad	ancho	profundidad útil	ancho útil
360	76.02 cm	66.22 cm	126.07 cm	111.14 cm

**INDICACIONES DE CONEXIÓN PARA EL ADECUADO FUNCIONAMIENTO**  
Características eléctricas nominales:


	tensión de alimentación	frecuencia	corriente
México y CA	115 V	60 Hz	0,99 A
Chile	220 V	50 Hz	
Uruguay	230 V	50 Hz	0,93 A

**NIVELACIÓN**  
Coloque el refrigerador sobre una superficie plana. Los tornillos niveladores están al frente del equipo, en la parte inferior.

Debe ajustarlos para que el aparato no se mueva durante el uso normal.  
Para nivelar el refrigerador se necesitan dos personas. Mientras una lo inclina un poco hacia atrás, la otra debe girar los tornillos en el sentido de las agujas del reloj. Entre el piso y la arista delantera debe haber 48 mm (1.9 in), aproximadamente.



Tras la nivelación, deje que el refrigerador repose de 6 a 8 horas. Antes de conectarlo, limpie el interior con una esponja suave y jabón neutro o bicarbonato de sodio disuelto en agua.



**CONTROL DEL ENFRIADOR**  
Gradúe la temperatura entre el mínimo y máximo marcados en el dial. Antes de hacer cualquier nuevo ajuste, espere de 4 a 6 horas y compruebe si el refrigerador alcanzó la temperatura deseada.

**Temperaturas recomendadas**  
**Mínima:** Días fríos, pocas cosas almacenadas, puertas regularmente cerradas.  
**Media:** Para el uso normal.  
**Máxima:** Días calientes, muchos alimentos almacenados, puertas que se abren con frecuencia.

- CONSEJOS DE GUARDADO**
- Al acomodar los alimentos, cuide que nada obstruya las salidas de aire.
  - No almacene latas. Traspase el contenido a otros depósitos con tapa (con esto evitará la contaminación de olores).
  - Para ahorrar energía, deje que los alimentos se enfrien un poco antes de guardarlos.
  - Guarde las aguas de sabor en depósitos tapados para que no se contaminen con otros olores y sabores.
  - No lave las frutas ni las verduras antes de meterlas en el refrigerador. Póngalas dentro de bolsas y solo lávelas antes de prepararlas.
  - Guarde las cebollas en bolsas.
  - La oscuridad y el frío favorecen la germinación del ajo. No es conveniente refrigerar esta hortaliza.
  - Abra las puertas el menor tiempo posible.
  - Haga porciones pequeñas para congelar. Esto ayuda a que circule el aire.
  - Antes de guardar productos, revise las fechas de caducidad.
  - Evite guardar bebidas gaseosas o efervescentes en el congelador.
  - Algunos productos, como los helados de agua, no deben consumirse demasiados fríos.
  - Cuando meta algo en el congelador por primera vez, no lo deje en contacto con algo ya congelado.
  - No utilice dispositivos mecánicos ni otros medios para acelerar el proceso de deshielo, salvo los que recomiende el fabricante.
  - No utilice aparatos eléctricos dentro de los compartimentos de almacenamiento de comida, salvo los que recomiende el fabricante.

**LUZ DEL REFRIGERADOR**  
Para cambiar el foco:  
1 desconecte el refrigerador;  
2 retire la cubierta del foco (tómela de la media luna superior y jale hacia usted);  
3 desenrosque el foco y consiga otro de las mismas características;  
4 monte el foco nuevo y reinstale la tapa. Al presionar la tapa de vuelta en su lugar debe oírse un clic.

**CALENTAMIENTOS Y CONDENSACIONES EXTERIORES**  
El sistema contra la condensación puede causar calentamientos en el exterior. Es normal. No obstante, en condiciones de alta temperatura y alta humedad en el ambiente, es posible que se forme una condensación ligera. Séquela con un trapo.

**Limpieza y conservación**

- Para limpiar su refrigerador y preservar su buen funcionamiento:
- siempre desconéctelo antes de cualquier revisión;
  - nunca use limpiadores tóxicos;
  - no use productos abrasivos, fibras ni objetos puntiagudos que puedan dañar las superficies;
  - utilice una esponja suave o un trapo humedecido y jabón neutro, enjuague las partes y séquelas con un trapo limpio y seco;
  - en la limpieza del interior, puede usar una cucharada de bicarbonato disuelta en dos litros de agua;
  - si bien las parrillas de cristal templado tienen bordes para contener un poco de líquido, limpie los derrames tan pronto como pueda;
  - cada seis meses, por lo menos, pase un cepillo, un trapo o una esponja por el condensador (el serpentín metálico que el refrigerador tiene por detrás).

**PRECAUCIONES GENERALES**  
La temperatura ambiente afecta el rendimiento del equipo. Seleccione una temperatura más fría si abre frecuentemente las puertas del refrigerador.  
Al guardar los alimentos, no obstruya las salidas de aire.  
Si tiene las manos mojadas, no toque el interior del congelador.

A veces, inmediatamente después de cerrar la puerta, cuesta trabajo abrirla de nuevo, pues el intercambio de aire a diferentes temperaturas crea un vacío. Basta con esperar de 10 a 15 segundos.  
**Importante:** Se considera que el aparato no ha sido usado de manera normal cuando:  
—su instalación u operación no se han hecho conforme al presente instructivo de uso en español;  
—ha sido utilizado para fines comerciales, industriales o de cualquier forma que sea diferente a las explicadas en las instrucciones de manejo;  
—ha sido reparado por personas o talleres de servicio no autorizados;  
—ha sufrido daños en actos de fuerza mayor o casos fortuitos.

**MUDANZAS**  
Enrosque un poco los tornillos niveladores. Si necesita acostar el refrigerador, hágalo únicamente sobre el costado izquierdo (viéndolo de frente).  
Tras haber colocado el refrigerador en el nuevo lugar, siga las instrucciones de instalación para que el gas refrigerante y el aceite del compresor se asienten.  
Se considera que el aparato no ha sido

(Continúa a la vuelta)

**Welcome**

Everything you need to know for running your refrigerator correctly can be found here. We invite you to get to know its features and take full advantage of what it has to offer.

**Quick Start Guide**

- 1** Select a clean, damp-free, spacious area.
- 2** Remove all packaging materials: tape, cardboard, plastic bags, Styrofoam, etc.
- 3** Installation Clearances  
Leave 5 cm (2 in) of space on both sides, 10 cm (4 in) behind, and 5-10 cm on top so that air can circulate.
- 4** Let the refrigerator stand for six to eight hours for the gas to settle.
- 5** Clean the refrigerator with a cloth or soft sponge and mild soap before connecting it.
- 6** Connect the refrigerator. Before using it, let it run empty and closed for four hours.

- Do not use extension cords.
- Do not connect other appliances in the same outlet.
- Take the cord by the plug. Never pull on the cable.
- The refrigerator has a Y-shaped polarized outlet with an integrated ground wire. Do not remove the ground wire or use adaptors.

**USE OF EXTENSION CORDS**  
Because of potential safety hazards under certain conditions, we strongly recommend against the use of an extension cord. However, if you still elect to use an extension cord, it is absolutely necessary that it be a UL listed 3-wire grounding type plug and outlet and that the electrical rating of the cord be 15 amperes (minimum) and 120 volts.  
If there are voltage variations where you live, use a voltage regulator with 500 to 1000 watt capacity.

**Warning:** Ignoring the above-mentioned advice places the responsibility of any personal or material risk entirely with the customer.

**General instructions**

**Important:**  
a) Read the technical instructions for installing this product.  
b) Read the operating instructions before turning on this product.


This product is not meant to be used by persons (including children) with physical, sensory or mental disabilities or those with a lack of experience and knowledge except when they have been given instruction or are supervised with regard to the use of the product by a person responsible for their safety.  
Children must be supervised to ensure they do not play with the refrigerator.

**PLACEMENT**  
Air must circulate around the refrigerator for it to work well. Review point three of the Quick Start Guide.  
**Note:** These models are not reversible. Do not place the refrigerator near a heat source (stove, oven, heater) or expose it to the sun.

**MINIMUM ELECTRICAL ENERGY REQUIREMENTS**

	Supply Voltage	Frequency	Current
Mexico and CA	115 V	60 Hz	0,99 A
Chile	220 V	50 Hz	
Uruguay	230 V	50 Hz	0,93 A

**LEVELLING**  
Place the refrigerator on a flat surface. The leveling screws are located on the bottom of the refrigerator at the front. Adjust them so that the product does not move during normal usage.



Two people are needed to level the refrigerator. While one person tilts it backward, the other must turn the screws clockwise. Between the floor and the edge there must be approximately 48 millimeters (1.9 inches).  
After leveling, let the refrigerator stand for six to eight hours. Before connecting it, clean the inside using a soft sponge and mild soap or baking powder dissolved in water.



**COOLING CONTROL**  
Adjust the temperature between the minimum and maximum levels marked on the dial. Before making another adjustment, wait four to six hours to be sure that the refrigerator has reached the desired temperature.

**Recommended Temperatures**  
**Minimum:** Cold days, few items stored, doors usually closed.  
**Medium:** For normal usage.  
**Maximum:** Hot days, many items stored, doors that are frequently opened.

**FOOD STORAGE ADVICE**  
1 When placing items in the refrigerator, be sure that nothing is blocking the air vents.  
2 Do not store cans. Transfer contents to storage containers with lids (eliminates odor contamination).

- To save energy, let food cool before storing it.
- Store juice in containers with lids so that it does not contaminate other food with odors and flavors.
- Do not wash fruit or vegetables before putting them in the refrigerator. Put them in a bag and wash them before using them.
- Store onions in bags.
- Darkness and cold favor garlic germination. It is not advisable to refrigerate this vegetable.
- Ensure that doors remain open for the least amount of time possible.
- Divide food into small portions for freezing. This helps air to circulate.
- Before storing products, check expiration dates.
- Avoid storing soda or sparkling beverages in the freezer.
- Some products, like ice pops, should not be consumed at too cold a temperature.
- When putting something in the freezer for the first time, do not let it come into contact with something that has already been frozen.
- Do not use mechanical devices or other means to accelerate the thawing process except as recommended by the manufacturer.
- Do not use electrical appliances inside the food storage compartments except as recommended by the manufacturer.

**REFRIGERATOR LIGHT**  
To change the bulb:  
1 Disconnect the refrigerator  
2 Pull back the bulb cover (hold the top half and pull towards yourself)  
3 Unscrew the bulb and replace it with one of the same  
4 Screw in the new bulb and reinstall the bulb cover. When putting the bulb cover in place, a click should be heard

**HEATING OF AREAS NEAR THE FREEZER**  
The anti-condensation system can cause heating of the exterior; this is normal. Nevertheless, in conditions of high heat and humidity it is possible that light condensation will develop. Dry it with a cloth.

**CLEANING AND UPKEEP**  
To clean the refrigerator and maintain it in good working order:  
• Always disconnect it before an inspection  
• Never use toxic cleaning products  
• Do not use abrasive products, fibers, or sharp objects that can damage surfaces  
• Use a soft sponge or damp cloth and mild soap to rinse inside the refrigerator and dry with a clean cloth  
• When cleaning the inside, a spoonful of baking soda dissolved in two liters of water may be used  
• Although the tempered glass shelves can contain some liquid, clean spills as soon as possible  
• Use a brush, cloth or sponge at least every six months to wipe down the condenser (the metal cooling coil on the back of the refrigerator)

**GENERAL PRECAUTIONS**  
Ambient temperature affects the refrigerator's efficiency. Select a colder temperature if the doors are frequently opened. When storing food, do not block the air vents. If your hands are wet, do not touch the inside of the freezer.  
Sometimes, immediately after closing the door, it is difficult to open again. The exchange of air of different temperatures creates a vacuum. Wait 10 to 15 seconds.  
**Important:** The product is considered to not be used in a normal way when:  
• Its installation or operation has not been carried out according to these usage instructions in Spanish  
• It has been repaired by unauthorized persons or service centers  
• It has been damaged by an act of God or unforeseen circumstances

**MOVING**  
Tilt the refrigerator backwards slightly and unscrew the leveling screws to avoid damage. If the product needs to be laid down, only do it on the left side (as seen from the front).  
After having positioned the refrigerator in its new place, follow the installation instructions so that the cooling gas and the air from the compressor have time to settle.  
The product is considered not to be used in a normal way when:  
• There is rust caused by dents, scratches, saline environments, etc. (Note that our authorized service centers offer maintenance and repair services and that these are charged at a reasonable price)  
• The product shows signs of damage because of improper use by the client, because of animal attacks (rodents, insects or others), because of dust or the environmental conditions where the product has been installed, such as humidity or excessive salinity.  
• It has been damaged while being transported by the buyer.

**TRIPS AND ABSENCES**  
If you are going to be away for more than two weeks, disconnect the refrigerator. Leave it clean and empty, including the ice trays. If possible, leave the doors half-open so as to prevent an accumulation of odors.

**POWER FAILURES**  
During the first four hours, the temperature in the refrigerator will not change very much. If the power outage lasts for more than six hours, put bags of ice in both the

(Continued on back)

